






Installationsanleitung UniRack 2
Installation guide UniRack 2
Instructions de montage UniRack 2



021.3041 / 021.3042 / 021.3043 / 021.3044 / 021.3052




B2




021.3062

C1




021.3066

C2




021.3061

C3



021.3064


D1




021.3060

D2

! Biegeradius
Bending radius




021.3211

E

021.3118

F1


Eingang links / Entry left



021.3056

F2


Eingang rechts / Entry right




021.3058

F3


1300 mm




021.3209

F4


021.3208

F5**Eingang links / Entry left****Eingang rechts / Entry right**

021.3055 / 021.3057

G

021.3067 / 021.3038

H

021.3046

Headquarters**Switzerland**

Reichle & De-Massari AG

Binzstrasse 32

CHE-8620 Wetzikon

Telephone HQ +41 (0)44 933 81 11

Telefax HQ +41 (0)44 930 49 41

E-Mail hq@rdm.comwww.rdm.com**R&M**